

## SLR050 Handle Seal Kit Installation Instructions

- 1. TURN OFF WATER, EITHER AT THE SUPPLY STOP OR AT THE WATER SYSTEM'S SOURCE. FLUSH CLOSET/URINAL TO RELIEVE PRESSURE.
- 1. SEAL
- 2. HANDLE ASSEMBLY
- 3. NUT
- 2. USING WRENCH, REMOVE
  NUT #3 AND PULL OUT
  HANDLE ASSEMBLY #2.
  3. CLEAN INSIDE OF BODY
  COMPLETELY AND REASSEMBLE
  WITH PARTS PROVIDED,
  FIRST MOISTEN NEW SEAL
  #1 BEFORE INSTALLING

  3.

P6000-M1-CP