



Swan Wax

Products - Cat 4 - Wax Gaskets, Cold Solders, and Lubricants



DESCRIPTION

Black Swan's Swan Wax is a 100% pure wax gasket for setting all floor outlet toilet bowls. The gasket forms a water tight, gas tight and odor tight seal. Fits 3" and 4" waste lines. Meets Federal Specification TT-P-1536A.

DIRECTIONS

1. Be sure the wax ring is at room temperature (about 70°F). If wax ring is too cold a good seal may not be made or the toilet bowl could crack while making the installation.
2. With the toilet bowl upside down on a protective pad or blanket, place the wax ring around the discharge opening. Press firmly to assure adhesion when the toilet is inverted.
3. Using Black Swan's Stainless or Stay Soft Putty make a putty ring about 1 inch high around the outside rim of the toilet. This will make a seal between the toilet rim and the floor.
4. Carefully set toilet down on bolts and twist bowl slightly to spread wax and putty to make a tight seal. Tighten bolts carefully to prevent breaking the bowl.

ACCESSORIES

Black Swan also sells Swan Wax with closet bolts included in the package. Since closet bolts are necessary to make the installation, this is a nice package to offer the end user. Stock Number 4001 is Swan Wax with two 1/4" X 2-1/4" brass bolts, two nuts, two washers, and two plastic stand-up washers. Stock Number 4002 is Swan Wax with two 1/4" X 2-1/4" brass plated bolts, two nuts, two washers, and two plastic stand-up washers.

STOCK NO.	SIZE	UPC NUMBER	CARTON CUBIC FEET
04000	--	0 54647 04000 4	1.37
04000-12	--	0 54647 04000 4	.33

04001	--	0 54647 04001 1	1.37
04002	--	0 54647 04002 8	1.37
MSDS			
Buy Now			

DESCRIPTION

Black Swan's Swan Wax is a 100% pure wax gasket for setting all floor outlet toilet bowls. The gasket forms a water tight, gas tight and odor tight seal. Fits 3" and 4" waste lines. Meets Federal Specification TT-P-1536A.

DIRECTIONS

1. Be sure the wax ring is at room temperature (about 70°F). If wax ring is too cold a good seal may not be made or the toilet bowl could crack while making the installation.
2. With the toilet bowl upside down on a protective pad or blanket, place the wax ring around the discharge opening. Press firmly to assure adhesion when the toilet is inverted.
3. Using **Black Swan's Stainless** or **Stay Soft Putty** make a putty ring about 1 inch high around the outside rim of the toilet. This will make a seal between the toilet rim and the floor.
4. Carefully set toilet down on bolts and twist bowl slightly to spread wax and putty to make a tight seal. Tighten bolts carefully to prevent breaking the bowl.

ACCESSORIES

Black Swan also sells **Swan Wax** with closet bolts included in the package. Since closet bolts are necessary to make the installation, this is a nice package to offer the end user. Stock Number 4001 is **Swan Wax** with two 1/4" X 2-1/4" brass bolts, two nuts, two washers, and two plastic stand-up washers. Stock Number 4002 is **Swan Wax** with two 1/4" X 2-1/4" brass plated bolts, two nuts, two washers, and two plastic stand-up washers.

STOCK NO.	SIZE	UPC NUMBER	CARTON CUBIC FEET
04000	--	0 54647 04000 4	1.37
04000-12	--	0 54647 04000 4	.33
04001	--	0 54647 04001 1	1.37
04002	--	0 54647 04002 8	1.37
MSDS			
Buy Now			