



Buy Factory Direct and Save



Sloan* V-551-A* Vacuum Breaker Installation Instructions STR651

1. VACUUM BREAKER
2. FLUSH TUBE
3. COUPLING NUT

1. TURN OFF WATER, EITHER AT SUPPLY STOP OR, AT THE WATER SYSTEM'S SOURCES. FLUSH CLOSET/URINAL TO RELIEVE PRESSURE.
2. USING WRENCH, UNSCREW RETAINING NUT AND COUPLING NUT #3 ON THE FLUSH TUBE #2. PULL OUT TUBE AND REMOVE VACUUM BREAKER #1.
3. CLEAN INSIDE OF VALVE BODY COMPLETELY AND REASSEMBLE WITH PARTS PROVIDED.

