



TYPE VI Filter Hook Install

1. Position fin between baffles on back side of filter.
2. Rotate over frame to engage hook on front side of filter.
3. Snap fit onto frame. Filter rivets will match fit with hook holes.