AQUASPEC® FAUCETS

MODEL - Z87100-XL SERIES Z87100-XL-HS SERIES KITCHEN SINK FAUCET



TECHNICAL INFORMATION

FLOW: 2.2 GPM [8.3 L] PRESSURE COMPENSATING AERATOR *

MAXIMUM PRESSURE: 125 PSI MAXIMUM TEMPERATURE: 180° F HANDLE NUT TORQUE: 15-20 FT - LBS.

CARTRIDGE STYLE: QUARTER TURN CERAMIC DISK

* OTHER AERATORS AVAILABLE BY REQUEST

INSTALLATION INSTRUCTIONS

- 1. REMOVE FAUCET BODY(#6) FROM CARTON AND APPLY PLUMBERS PUTTY TO UNDERSIDE OF BODY. (REFER TO FIGURE 1).
- 2. PLACE FAUCET ON SINK AND REMOVE MOUNTING NUTS (#7A) FROM BAG G60502.
- 3. HAND TIGHTEN MOUNTING NUTS (#7A) FROM UNDER SINK. MAKE SURE FAUCET IS CENTERED PROPERLY. **DO**NOT OVER TIGHTEN.
- 4. OPTIONAL HOSE SPRAY (REFER TO FIGURE 2)
 REMOVE HOSE SPRAY ASSEMBLY (#11) FROM PACKAGING. REMOVE MOUNTING NUT FROM HOSE SPRAY HOLDER
 (#11B) AND INSERT HOSE SPRAY HOLDER THROUGH FIXTURE. ASSEMBLE MOUNTING NUT ONTO HOSE SPRAY
 HOLDER AND TIGHTEN. DO NOT OVER TIGHTEN. INSERT THREADED END OF HOSE SPRAY (#11A) THROUGH HOSE
 SPRAY HOLDER (#11B) AND CONNECT HOSE SPRAY (#11A) TO DIVERTER ADAPTOR (#10). TIGHTEN TO CREATE A
 WATER TIGHT CONNECTION.
- 5. ATTACH LAVATORY SUPPLIES TO FAUCET WITH RISER NUTS (ITEM #7B).
- 6. OPTIONAL GRID STRAINER (-G) / HANDICAP OFFSET GRID DRAIN (-GH) INSTALL GRID STRAINER IN SINK OUTLET AND PLUMB WASTE CONNECTION.
- 7. INSTALL SPOUT INTO BASE AND TIGHTEN NUT (SEE VIEWS FOR SWING/RIGID CONNECTION).
- 8. TURN SUPPLY WATER ON AND OPERATE FAUCET CHECKING FOR LEAKS.
- 9. REPLACE HANDLE SCREWS AND COLOR INDEX BUTTONS.
- 10. INSTALL AERATOR INTO FAUCET AND HAND TIGHTEN. IT MAY BE NECESSARY TO UNSCREW AND CLEAN AERATOR AT START-UP.

ZURN INDUSTRIES, LLC ♦ COMMERCIAL BRASS OPERATION ♦ 2640 SOUTH WORK STREET ♦ FALCONER NY 14733 Phone: 1-800-997-3876 ♦ Fax: 1-919-775-3541 ♦ www.zurn.com

In Canada: ZURN INDUSTRIES LIMITED ♦ 3544 Nashua Drive ♦ Mississauga, Ontario L4V1L2 ♦ Phone: 905/405-8272 Fax: 905/405-1292

MAINTENANCE


- 1. YOUR ZURN AQUASPEC FAUCET HAS A HIGHLY POLISHED NICKEL CHROME PLATED FINISH. CLEAN WITH SOAP AND WATER OR A MILD CLEANER WHICH IS SAFE FOR CHROME PLATING. DO NOT USE ACIDS OR TOILET BOWL CLEANER AS THEY WILL DAMAGE THE FINISH.
- 2. AQUASPEC FAUCETS CONTAIN CERAMIC DISK CARTRIDGES WHICH REQUIRE NO MAINTENANCE. TO REMOVE THE CARTRIDGE, SHUT THE WATER OFF, LOOSEN THE HANDLE NUTS AND PULL UP ON THE CARTRIDGE.

REPLACEMENT PARTS

COLD WATER CARTRIDGE HOT WATER CARTRIDGE INDEX BUTTONS 59517005 59517006 G60500 HOSE SPRAY AND HOLDER G67905

Z871B1-XL PICTURED

FIGURE 1




Z87100-XL PARTS LIST

ПЕМ		QTY	ΠΈΜ	QTY
2 595 3 595	40001 HANDLE NUT 17005 SHORT COLD CARTRIDGE 17006 SHORT HOT CARTRIDGE 67005 BASE	2 1 1 1	5 58155019 O-RINGS 6 93286001 KITCHEN DECK BO 7 G60502 NUTS 7A 59530002 MOUNTING NUT 7B 59532001 1/2" NPSM RISER	1 2

Z871B1-XL-HS PICTURED

FIGURE 2



Z87100-XL-HS PARTS LIST

ПЕМ	QTY	ПЕМ	QTY
1 59440001 2 59517005 3 59517006 4 60467006 5 58155019 6 93286002 7 G60502 7A 5953000 7B 5953200	 2 1 1 1 1 1 1 1 2 2	8 93217001 DIVERTER 9 58155015 O-RING 10 60943002 DIVERTER ADAPTOR 11 G67905 HOSE ASS'Y	1 1 1 1